

Hamilton Beach
Good Thinking®

12 Cup BrewStation® Coffeemaker



Product Name/MSRP

Hamilton Beach® 12 Cup BrewStation® Coffeemaker
(Model 47700)
MSRP: \$59

Availability

July 2011

Toll-Free Number and Web Site

800-851-8900; www.hamiltonbeach.com

Media Contact

Mary Beth Brault 804-418-8868
marybeth.brault@hamiltonbeach.com
Twitter: [@hamiltonbeachmb](https://twitter.com/hamiltonbeachmb)

Press Room

Go to www.hamiltonbeach.com and click "press room."
Images of Hamilton Beach® products on-line at
<http://www.hbps-imagebank.com>



Good Thinking® Features

No carafe means no hassle – It also means no pouring, no spilling, no breaking, no burnt coffee flavor. With one-hand dispensing, you get the perfect amount of fresh, flavorful coffee every time.

Keep coffee fresher longer – Our gentle warming heater maintains the coffee's temperature. Since there is no hot plate, you won't scorch your coffee.

Your coffee, your way – choose bold, regular or small batch.

Good coffee starts with good water – Unwanted chemicals in your water can lead to unwanted flavors in your coffee. Thanks to our water filter, you can start every cup of coffee with clean water. A built in feature lets you know when it is time to clean your BrewStation® coffeemaker. And with a convenient brew tank handle, filling the water reservoir is easy.

BrewStation® Coffeemaker Cleaning 1-2-3

All coffeemakers should be cleaned at least once a month (once a week for areas with hard water). The BrewStation® coffeemaker even lets you know when its time for cleaning. When unit senses residue buildup, CLEAN will appear in display.

- Remove water filter; pour 1 pint (2 cups/500 ml) vinegar into water reservoir.
- Press ON. Turn OFF after 30 seconds and wait 30 minutes.
- Press ON. Turn OFF when finished. When cool, dispense several cups before emptying and rinsing reservoir.
- Remove filter basket and coffee tank, wash by hand with warm, soapy water. (Coffee tank may also be cleaned in top rack of dishwasher.) Clean filter basket often.
- Outside of coffeemaker may be cleaned with a soft cloth and warm, soapy water. Do not use abrasive cleaners, since they will scratch the finish.

Tips from the Hamilton Beach Brands Test Kitchen