

Hamilton Beach® Breakfast Sandwich Maker



Product Name/MSRP:

Hamilton Beach® Breakfast Sandwich Maker
Models: 25475 (Gray), 25476 (Red), 25477 (Black)
MSRP: \$29.99

Availability

25475 now; 25476 & 25477 July, 2013

Toll-Free Number and Web Site

800-851-8900; www.hamiltonbeach.com

Media Contact

Mary Beth Brault 804-418-8868

marybeth.brault@hamiltonbeach.com



<http://facebook.com/hamiltonbeach>

[@HamiltonBeachMB](https://twitter.com/HamiltonBeachMB)

<http://youtube.com/hamiltonbeachbrands>

Press Room

Go to www.hamiltonbeach.com and click "press room."

Images of Hamilton Beach® products online at

<http://www.hbps-imagebank.com>



Good Thinking® Features

Make a Breakfast Sandwich in Minutes! – Forget the fast food drive-through. With the Hamilton Beach Breakfast Sandwich Maker, you can enjoy a hot, homemade breakfast sandwich in under 5 minutes.

Endless Variety – You choose your favorite ingredients, the possibilities are endless! Whether you prefer ham, egg and cheese on an English muffin or turkey sausage with egg whites and spinach on a bagel, the Breakfast Sandwich Maker is an easy and affordable way to get a hot breakfast sandwich you can take on the go or stay and enjoy.

Easy to Use – Simply place the ingredients inside, building your sandwich with the egg (or other internal ingredients) on the cooking plate, and close the lid. Slide the cooking plate out and your sandwich assembles itself. Open the lid and your hot breakfast sandwich is ready to eat.

Easy to Clean – Cooking surfaces are nonstick. Ring with egg cooking plate is removable and dishwasher-safe.

Egg, Ham and Cheese Breakfast Sandwich

INGREDIENTS

- 1 English Muffin, split
- 1 slice pre-cooked Canadian bacon or ham
- 1 egg
- 1 slice American cheese

1. Preheat Breakfast Sandwich Maker 5 minutes. Lift cover, top ring and heating plate.
2. Place half of muffin, split side up in bottom ring of Breakfast Sandwich Maker. Top with Canadian bacon or ham.
3. Lower heating plate and top ring. Add egg to plate. Pierce yoke with a toothpick.
4. Top with cheese and remaining muffin half, split side down.
5. Close cover. Cook 4 minutes. Move heating plate handle to left. Lift cover and rings and carefully remove sandwich with plastic spatula.